







Timer per la regolazione del tempo di cottura • Timer for setting the cooking time • Timer zur Einstellung der Kochzeit
 Minuterie pour régler le temps de cuisson • Temporizador para el ajuste del tiempo de cocción.



	SMALL E	SMALL E2
		
DIMENSIONI INTERNE cm INSIDE DIMENSIONS cm INNENABMESSUNGEN cm DIMENSIONS INTERNES cm DIMENSIONES INTERIORES cm	4136 11	4136 11(x2)
DIMENSIONI ESTERNE cm OUTSIDE DIMENSIONS cm AUSSENABMESSUNGEN cm DIMENSIONS EXTERNES cm DIMENSIONES EXTERIORES cm	55 43 25,5	55 43 43,5
DIMENSIONI IMBALLO cm PACKAGE DIMENSIONS cm ABMESSUNGEN DER VERPACKUNG cm DIMENSIONS EMBALLAGE cm DIMENSIONES DEL EMPAQUE cm	60 50 28	60 50 46
CAMERA COTTURA n° BAKING CHAMBER n° BACKKAMMER n° CHAMBRE DE CUISSON n° CAMARA DE COCCIÓN n°	1	2
POTENZA Kw POWER Kw - LEISTUNG Kw PUISSANCE Kw - POTENCIA Kw	1,6	3,2
VOLT	230	230
TEMPERATURA C° TEMPERATURE C° - TEMPERATUR C° TEMPERATURE C° - TEMPERATURA C°	0/320°	0/320°
PESO Kg WEIGHT Kg - GEWICHT Kg POIDS Kg - PESO Kg	21	32
TOTALE PIZZE Ø 33 cm TOTAL PIZZA Ø 33 cm GESAMTZAHL PIZZEN Ø 33 CM TOTAL DES PIZZAS Ø 33 cm TOTAL PIZZAS Ø 33 cm		
CODICE - CODE - CODE - CODE - CÓDIGO	7020121001E	7020121002E